








# GENERATOR SERVICE INSTRUCTIONS

Camlab  
01954 233100

## DISASSEMBLY

## ASSEMBLY

| 5mm 7mm 10mm                                                                              | 20mm                                                                               | 32mm – 55mm                                                                         |
|-------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| 1 Insert and hold probe tool.                                                             | 1 Insert and hold probe tool.                                                      | 1 Insert and hold knife tool.                                                       |
|          |  |  |
| NEXT                                                                                      |                                                                                    |                                                                                     |
| 2 Insert other probe tool and turn counter-clockwise while holding knife tool stationary. |                                                                                    |                                                                                     |
|        |                                                                                    |                                                                                     |
| NEXT                                                                                      |                                                                                    |                                                                                     |
| 3 Remove knife.                                                                           |                                                                                    |                                                                                     |
|        |                                                                                    |                                                                                     |
| NEXT                                                                                      |                                                                                    |                                                                                     |
| 4 Remove shaft and upper bearing.                                                         |                                                                                    |                                                                                     |
|        |                                                                                    |                                                                                     |
| NEXT                                                                                      |                                                                                    |                                                                                     |
| 5 Remove upper bearing from shaft.                                                        |                                                                                    |                                                                                     |
|        |                                                                                    |                                                                                     |


The lower bearing will come out with little effort. Remove the lower bearing and the parts are ready for cleaning.

OR

A press is required to remove the lower bearing from 5 & 7mm generator probes. The process is illustrated below.


NEXT

6 Thread appropriate bearing press onto shaft.



NEXT

7 Insert shaft with bearing press into generator tube.



NEXT

8 Press bearing out of generator tube.



NEXT

9 Remove bearing press before cleaning.




**CAUTION**  
DO NOT use any tools other than those illustrated. Use of any other tool will void your warranty. Contact the service department if a tool kit is required.

**WARNING**  
Generator probe and knife may be sharp. Always use caution when working with any sharp objects.

**CAUTION**  
DO NOT tighten generator probe parts. Use of any torque may damage the generator probe or complicate assembly and disassembly.

### WHAT SIZE GENERATOR PROBE DO YOU HAVE?

Match the bottom of your generator probe to the circles shown below to determine the diameter of the probe. Reference the manual for a complete listing of parts and assembly numbers.



**NOTE** Inspect bearing for wear or black particles. Clean any dirt from bearing before reassembly. Replace bearing if worn or damaged.

**NOTE** If bearings are replaced, they must be run-in before initial use.

**NOTE** 195mm length generator probes may have a mid-bearing pressed into the tube. The tube can be autoclaved with the mid-bearing installed. If you must remove the mid-bearing, contact the service department.



## RUN-IN PROCEDURE

New bearings must be run-in before initial use.


Procedure:

1. Run 4 minutes on lowest motor setting.
2. Run 5 minutes on medium motor setting.
3. Run 1 minute on highest motor setting.
4. Disassemble generator probe.
5. Clean bearings of run-in dust.
6. Reassemble generator probe.

Generator probe is ready for use.


| 5mm 7mm 10mm                                                                        | 20mm                                                                                 | 32mm – 55mm                                                                           |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| 5 Insert probe tool.                                                                | 5 Insert probe tool.                                                                 | 5 Insert knife tool.                                                                  |
|  |  |  |

6 Turn rotor shaft clockwise with shaft tool.



**CAUTION:** Turn shaft until assembly stops. DO NOT TIGHTEN.

7 Run generator in water. Knife will self tighten.



CLEANING GENERATOR PROBES

Generator probes are configured with a Teflon upper and lower bearing (400-series stainless steel bearings may be ordered). Please note that 400-series stainless steel bearings are subject to corrosion if not properly maintained. After cleaning, stainless steel bearings should be removed from the generator probe and wiped clean of all debris and moisture. Stainless steel bearings should not be used when working with organic solvents or in an environment that does not allow for proper maintenance. If the generator probe is to be used with organic solvents, then it is recommended that the stainless steel bearing be replaced with a glass filled Teflon bearing (PN 10503). Teflon bearings are generally corrosion resistant, and are self-lubricating.

CAUTION: DO NOT autoclave or lubricate stainless steel bearings.

Generator probes can be autoclaved as a complete assembly, if Teflon bearings are used. However, if it is necessary to disassemble the generator probe for special cleaning, or replacement of the rotor knife, rotor shaft, or the bearings, then follow the disassembly introductions.

NOTE: If you experience excessive vibration, heat, or bearing wear, please contact technical support at 1-800-776-4431

REPLACEMENT AND RUN-IN OF TEFLON BEARINGS

Over time, and with repeated use, Teflon bearings will wear out and must be replaced. Failure to replace worn Teflon bearings will result in damage to the generator probe. Teflon bearings should be replaced when they no longer fit snugly against the rotor shaft, or when visible wear is apparent, or if black particles become visible in the sample.

**Run-in:** The new bearing must be run-in in order to assure proper seating and to operate properly. Immerse one-third of the generator probe in water and operate the motor drive at low speed for 5 minutes, then run at full speed for 1 minute to complete the run-in procedure. If excessive or unusual noise is experienced during the run-in, immediately turn off the motor drive, and restart the break-in procedure at low speed. After completion of the run-in procedure, disassemble the generator probe and clean the bearing. Reassemble the generator probe and operate as needed.

WARNING: The tip of the generator probe, especially on the saw tooth generator probes, is sharp. For safety purposes it is advisable that the protective cap be replaced on the generator probe when not in use.

CAUTION: The bottom of the generator probe is extremely fragile and care should be taken to protect it. Replace the blue protective cap on the end of the generator probe when the generator probe is not being used.

CAUTION: When using Teflon lower bearings, immerse the bottom of the generator probe in liquid or in the sample to avoid premature failure of the lower bearing.


NOTE: For optimal sample recovery during processing, completely remove the generator probe from the sample prior to turning off the motor drive unit.

NOTE: Liquid circulates through the two holes in the generator probe. DO NOT block the upper hole, although the lower hole may be completely submerged during processing.


CAUTION: To protect the motor and the generator probe never operate the motor with the generator probe partially threaded onto the motor.




GENERATOR PROBES FOR OMNI μH, TH, GLH, & PDH



5-10mm Generator Probe




20mm Generator Probe



32-35mm Generator Probe

GENERATOR PROBE REPLACEMENT PARTS



| Generator   | Diameter | Length | Shaft     | Upper Bearing |           | Lower Bearing |           | Knife     | Mid Bearing |
|-------------|----------|--------|-----------|---------------|-----------|---------------|-----------|-----------|-------------|
|             |          |        |           | Teflon        | S.S.      | Teflon        | S.S.      |           |             |
| A           |          |        | C         | D (4/pkg)     | D (2/pkg) | E (4/pkg)     | E (2/pkg) | F         | G           |
| G5-95       | 5mm      | 95mm   | 5952      | 10503         | 10651     | 10505         | N/A       | 10045     | N/A         |
| G5-95W      | 5mm      | 95mm   | 5952      | 10503         | 10651     | 10505         | N/A       | 10045     | N/A         |
| G7-95       | 7mm      | 95mm   | 7952      | 10503         | 10651     | 10507         | N/A       | 10047     | N/A         |
| G7-95ST     | 7mm      | 95mm   | 7952      | 10503         | 10651     | 10507         | N/A       | 10047     | N/A         |
| G7-95STW    | 7mm      | 95mm   | 7952      | 10503         | 10651     | 10507         | N/A       | 10047     | N/A         |
| G7-95W      | 7mm      | 95mm   | 7952      | 10503         | 10651     | 10507         | N/A       | 10047     | N/A         |
| G7-195      | 7mm      | 195mm  | 71952     | 10503         | 10651     | 10507         | N/A       | 10047     | 10071_R     |
| G7-195ST    | 7mm      | 195mm  | 71952     | 10503         | 10651     | 10507         | N/A       | 10047     | 10071_R     |
| G7-195STW   | 7mm      | 195mm  | 71952     | 10503         | 10651     | 10507         | N/A       | 10047     | 10071_R     |
| G10-95      | 10mm     | 95mm   | 10952     | 10503         | 10651     | 10504         | 10652     | 15013     | N/A         |
| G10-95W     | 10mm     | 95mm   | 10952     | 10503         | 10651     | 10504         | 10652     | 15013     | N/A         |
| G10-95K     | 10mm     | 95mm   | 10952     | 10503         | 10651     | 10504         | 10652     | 15013-B   | N/A         |
| G10-95KW    | 10mm     | 95mm   | 10952     | 10503         | 10651     | 10504         | 10652     | 15013-B   | N/A         |
| G10-195     | 10mm     | 195mm  | 101952    | 10503         | 10651     | 10504         | 10652     | 15013     | 10069       |
| G10-195W    | 10mm     | 195mm  | 101952    | 10503         | 10651     | 10504         | 10652     | 15013     | 10069       |
| G10-195K    | 10mm     | 195mm  | 101952    | 10503         | 10651     | 10504         | 10652     | 15013-B   | 10069       |
| G10-195KW   | 10mm     | 195mm  | 101952    | 10503         | 10651     | 10504         | 10652     | 15013-B   | 10069       |
| G20-195ST   | 20mm     | 195mm  | 201952    | 10503         | 10651     | 10503         | 10651     | 15023     | 10069       |
| G20-195STW  | 20mm     | 195mm  | 201952    | 10503         | 10651     | 10503         | 10651     | 15023     | 10069       |
| G20-195STK  | 20mm     | 195mm  | 201952    | 10503         | 10651     | 10503         | 10651     | 15023-B   | 10069       |
| G20-195STKW | 20mm     | 195mm  | 201952    | 10503         | 10651     | 10503         | 10651     | 15023-B   | 10069       |
| G-32TT-195  | 32mm     | 195mm  | 15-05-195 | 10506         | 10653     | 10506         | 10653     | 15-03-32T | 15-11-250   |
| G-35NA-195  | 35mm     | 195mm  | 15-05-195 | 10506         | 10653     | 10506         | 10653     | 15-03-35A | 15-11-250   |
| G-35WA-195  | 35mm     | 195mm  | 15-05-195 | 10506         | 10653     | 10506         | 10653     | 15-03-35A | 15-11-250   |