		mobile unit	upper basket	drying connection	conversion	conversion	conversion	spacer	
	application	٤		٩	kit 1 (US 1)	kit 2 (US 2)	kit 3 (US 3)	tube	stop
	dental (dental hand-pieces and turbines)		Χ				Х	Х	Х
	Injektorkorb						Х	Х	Х
	laboratory (narrow-necked glassware)	Х				Х			
	laboratory (narrow-necked glassware)	Х		Х	X				
	laboratory (narrow-necked glassware)	Х		Х	X				
	laboratory (narrow-necked glassware)	Х				X			
	laboratory (narrow-necked glassware)	Х				X			
	laboratory (narrow-necked glassware)		Х		Х				Х
E 385	laboratory (narrow-necked glassware)	Х		Х	X				
O 187	laboratory (narrow-necked glassware)		х				x	х	х
E 355	laboratory (narrow-necked glassware)	Х				X			
	laboratory (narrow-necked glassware)	Х		Х	Х				
U 175	laboratory (narrow-necked glassware)	Х							
E 331	laboratory (narrow-necked glassware)	Х				X			
E 406	laboratory (pipettes)	Х					X		
E 405/1	laboratory (pipettes)	Х		Х	Х				
E 404	laboratory (pipettes)	Х					Х		
O 184	laboratory (test tubes)		Х		Х			Х	Х
U 184/1	laboratory (test tubes)	Х							
O 188/2	laboratory / medical						Х	Х	Х
O 190/2	laboratory / medical / dental						Х	Х	Х
O 191/2	medical						Х	Х	Х
E 435/3	medical (anesthesia)	Х		Х	Х				
E 501	medical (anesthesia)	Х		Х	X				Х
E 368	medical (anesthesia)	Х		Х	Х				
E 367	medical (anesthesia)	Х		Х	Х				
	medical (anesthesia)	Х		Х	Х				
E 461/2	medical (anesthesia)	Х		Х	Х				
E 450/1	medical (MIS)	х		Х	Х				Х
O 176	medical (MIS)		х	Х	Х			х	Х
	medical (ophthalmology)	х					Х		
	medical (theatre shoes)						Х	Х	Х
	medical (theatre shoes)						Х	Х	Х