3M Personal Safety



3M[™] 600 Series Headtops HT-629





Before Use

- Inspect Comfort Band remove and replace if necessary
- Inspect Face Seal ensure it is free from holes or tears
- Ensure shield angle and head harness size are correctly set
- Ensure Pivot Nuts are secure
- Ensure Welding Filter and Cover Lenses are correctly fitted and undamaged
- Ensure correct shade setting is selected
- Inspect Head Harness and Air Duct
- Ensure all parts are free from cracks and splits replace if necessary

Monthly

 Carry out all the 'Before Use' inspections and create record of this monthly check

After Use

- Clean with cloth dampened with a mild solution of water and liquid household soap
- Disinfect with 3M[™] 105 Wipes
- Store in a dry, clean area / locker away from direct sunlight, high temperatures and solvents


Ordering Consumables, Repair Parts and Accessories


To request a quote or place an order for these items, please contact your 3M Approved Distributor.

Further Information and Advice

If you require additional guidance on the Care and Maintenance of your 3M Powered and Supplied Air Equipment, please contact the Helpline or your local 3M representative.







The solution for welders needing a welding shield with a wide-view clear visor beneath. The 90 x 110mm holder hinges down for easy access. Conventional or auto-darkening filters can be fitted.



3M Personal Safety Division 3M United Kingdom plc 3M Centre

3M Centre Cain Road, Bracknell Berkshire RG12 8HT Tel: 0870 60 800 60 www.3M.co.uk/Safety **3M Ireland Limited** The Iveagh Building

 The Park
 17808

 Carrickmines
 3M is a trad

 Dublin 18
 Please recy

 Tel: 1 800 320 500
 © 3M 2014

17808
3M is a trademark of 3M Company
Please recycle. Printed in UK.

© 3M 2014. All rights reserved.

REPLACE ALL DAMAGED PARTS IMMEDIATELY TO ENSURE CORRECT LEVELS OF PROTECTION



CHHT629CMP

To download this poster please visit: www.3M.co.uk/maintenancepack or scan the QR code

