

# Care and Maintenance

## 3M<sup>™</sup> Versaflo<sup>™</sup> M-400 Series Helmets

To maintain protection levels, optimise the effective lifetime of the system and avoid the additional cost of replacement, it is extremely important to carry out regular checks and maintenance.

### **▶** Before Use

- Inspect for damage and replace if necessary:
- Outer shroud ensure it is free from tears and its gasket is inserted properly
- Inner collar
- Visor frame to jaw gasket
- Visor surround and gasket
- Helmet shell
- Forehead seal
- Head harness
- Comfort pad/s
- Replace Peel Off visor covers (if used).

## Monthly

 Carry out all the 'Before Use' inspections and create record of this monthly check.

#### After Use

- Clean with cloth dampened with a mild solution of water and liquid household soap.
- Disinfect with 3M 105 Wipes.
- Store in a dry, clean area / locker away from direct sunlight, high temperatures and solvents.

## Ordering Consumables, Repair Parts and Accessories

To request a quote or place an order for these items, please contact your 3M Approved Distributor.


#### Further Information and Advice

If you require additional guidance on the Care and Maintenance of your 3M Powered and Supplied Air Equipment, please contact the Helpline or your local 3M representative.

3M Personal Safety Division 3M United Kingdom plc 3M Centre, Cain Road Bracknell, Berkshire RG12 8HT United Kingdom Tel: 0870 60 800 60 www.3M.co.uk/safety

3M Ireland Limited The Iveagh Building The Park Carrickmines Dublin 18 Tel: 1 800 320 500

Please recycle. Printed in UK. 3M is trademarks of the 3M company. © 3M 2015. All rights reserved. J308790



Replace all damaged parts immediately to ensure correct levels of protection.



CHM400CMF

To download this poster please visit:

www.3M.co.uk/maintenancepack or scan the QR code.

For more information on all our products, call 3M Personal Safety Division on 0870 60 800 60 (UK) and 1800 320 500 (Ireland) or visit www.3M.co.uk/safety



	Description	Part N°
	Versaflo M-406 Respiratory Helmet, with Coated Visor and High Durability Shroud	M-406
	Versaflo M-407 Respiratory Helmet, with Coated Visor and Flame Resistant Shroud	M-407
	Accessories and spare parts	
01	Replacement Airflow Deflector	M-316
02	Head Suspension	M-350
03	Jaw Gasket	M-441
04	Inner Collar	M-444
05	Flame Resistant Outer Shroud (M-407)	M-447
05	High Durability Outer Shroud (M-406)	M-448
06	Size Reducing Ratchet Comfort Pad	M-956
07	Forehead Comfort Pad	M-957
80	Visor Frame Buttons	M-919
09	Visor Frame Assembly	M-920
10	Visor Gasket	M-921
11	Molten Metal Visor	M-925
11	Coated Visor	M-927
12	Peel-Off Visor Covers	M-928
13	Chin Strap	M-958
14	Visor Pivot Kit	M-960
15	Flame Resistant Headtop Cover	M-972

@3M\_UK\_Safety



3M Health & Safety Helpline

Monday - Friday 9 to 5

0870 60 800 60 - UK 1800 320 500 - IRELAND