

## 3M™ Welding Headtops

3M™ Welding Headtops, used in conjunction with the TR-300, Jupiter and V-500 Respiratory Systems, provide comfortable protection for welding applications.



HT-629 Welding Headtop



HT-639 Welding Headtop

### Comfort

- ✓ Easily fitted face seal in a knitted, breathable, elasticised material
- ✓ No seams next to face - feels much cooler

### Filters

- ✓ Hinge on filter holder for easy access
- ✓ Able to hold conventional glass or auto-darkening filters
- ✓ Incorporates clear visor to enable the welder to inspect the weld comfortably without losing respiratory protection (HT-629 includes a wide-view, clear visor)
- ✓ A 3M BT-40 breathing tube must be used with the HT-639

### Assigned Protection Factor (APF)

- ✓ When used with TR-300, Jupiter or V-500 - APF 20



### HT-749 Welding Headtop

This helmet provides integrated head, eye, welding and respiratory protection.

- ✓ UK-sized aperture (31/4" x 41/4" - 108 x 82mm)
- ✓ Independent welding and clear-view visors allow grinding and respiratory protection with welding visor up
- ✓ Supplied with polycarbonate visors with medium energy eye impact and molten metal protection (EN 166:B:9)
- ✓ Assigned Protection Factor (APF): when used with TR-300, Jupiter or V-500 - APF 20



### Speedglas™ Welding Headtop

The Speedglas 9000 welding headtop is a face, eye and respiratory protective system for increased comfort and safety in welding.

- ✓ Headtop features shade 5 side windows
- ✓ Combine with a Speedglas Auto-darkening Filter (see right)
- ✓ Includes headtop and hose
- ✓ Assigned Protection Factor (APF): when used with TR-300 or Jupiter - APF 20



### Speedglas™ 9002 Auto-darkening Welding Filters (for use with the Speedglas™ Welding Headtop)

The 9002 range offers a choice of three auto-darkening filters with variable shades, normal or large viewing areas plus sensitivity and delay adjustments.

- ✓ Constant protection from ultraviolet and infrared radiation
- ✓ Consistent auto-switching from clear to dark and back again in just the way the welder wants
- ✓ Eliminates neck strain of 'shield flipping' while greatly increasing the accuracy of electrode placement

**Speedglas 9002X** - Variable shades 9-13 (larger view)

**Speedglas 9002V** - Variable shades 9-13

**Speedglas 9002D** - Dual shades 9/11