

## Characteristics Cleanroom Plus 2 with castors

Article	9181 Artificial leather	
Dimensions in mm	Backrest:	H 380
	Seat:	H 440-565 W 480 D 470
	Weight:	14,0 kg
Packaging data	Volume:	0,19 m <sup>3</sup>



### Basic equipment

### Benefit

Suitability for cleanrooms	Air purity level 3 according to DIN EN ISO 14644-1 Air purity level 1 according to US-Fed St. 209E Sealed upholstery with special foam technology Materials that are suitable for use in clean rooms Smooth, sealed surfaces	Certified suitability for clean rooms  It can be ensured that no particles are emitted  The build-up of particles on the chair are avoided
Conductivity	The metal components have a conductive coating Volume conductive plastic parts The high-comfort upholstery is also conductive Typical discharge resistance of 10 <sup>6</sup> Ω Conductive castors/glides	Exceeds the requirements of ESD protection according to standard DIN EN 61340-5-1 100% ESD protection
Backrest	Large, ergonomically designed backrest to take the strain off the spine and muscles with integrated lumbar support	Healthy posture due to a hump providing support for the back in the lumbar region
	Backrest height adjustment convenient and easy to handle in sitting position	The support area can be adapted in accordance to the user's body size
Seat	Ergonomically designed seat with integrated pelvic support and rounded front edge	The seat automatically encourages the correct posture and upright, healthy sitting The round front edge of the seat prevents blocked circulation in the thighs
Finishes for seat and backrest	<b>ESD synthetic leather upholstery:</b> High-level ESD synthetic leather Skai Tundra. Resistant to disinfectants, washable and easy-care Colour: black (2571)	The soft and comfortable upholstery provides a comfortable feel However, damages caused by sharp parts can not be excluded Ideal for the use in production and laboratory
Seat height	Stepless seat height setting from 440-565 mm supported by safety gas spring with protective cover	Seat height can be adapted to nearly 95% of all body sizes
Functions / Mechanism	Permanent contact backrest	This mechanism ensures that the backrest responds immediately to any movements of the upper body by following them Thus, the back remains supported all the time The backrest can also be locked into any tilt position if required
	Quick adjustment	Every function can be operated comfortable and easy in sitting position
Base	The chairs are supplied with a brilliantly polished and wearproof aluminium 5 star base	Very high stability, longevity
Castors	Conductive Dual-wheel safety castors with load-sensitive brakes, For hard floors as standard	Chairs are braked when not used which decreases the accident risk
Materials	The materials used are recyclable	Environmentally friendly
Standards	DIN EN ISO 14644-1 DIN 61340-5-1 DIN 68 877	Certified suitability for clean rooms  100% ESD protection
	German GS "safety tested" mark of conformity Quality Management System DIN EN ISO 9001 Regulation EWG Nr. 1836/93 und Environmental Management System DIN EN ISO 14001	Procuring is insured
Warranty	5 year long term warranty, 3 years full warranty	Guaranteed quality and high efficiency

---

---

**Accessories and options**

Armrests	Loop armrests	Made of polyamide, adjustable in width (20 mm)
Accessories	Foot ring	The foot ring can be retrofitted by attaching it to the chair column
Options	Seat height 480-640 mm ESD „Mushroom glides“	

---