

Characteristics Laboratory Basic 2 with castors

Article	9134
Dimensions in mm	Backrest:: H 530
	Seat: H 470-610 W 460 D 440
	Weight: 17,0 kg Volume: 0,16 m ³



Basic equipment

Benefit

Laboratory qualification	Special art. Leather surface with antibacterial, antifungal and antimicrobial capacities.	Laboratory-appropriate equipment Washable, disinfectable and easy-care
Backrest	Large, ergonomically designed backrest to take the strain off the spine and muscles with integrated lumbar support	Healthy posture due to a hump providing support for the back in the lumbar region
	Backrest height adjustment convenient and easy to handle in sitting position	The support area can be adapted in accordance to the user's body size
Seat	Ergonomically designed seat with rounded front edge	The round front edge of the seat prevents blocked circulation in the thighs
Seat and backrest design	Synthetic leather cushion with seamless upholstery technique and high quality Skai synthetic leather. Washable and resistant to disinfectant. Available in the colors: Blue (6902) Red (6903) Black (2571) Grey (6911)	The extra-strong comfort upholstery offers excellent seating comfort. Soft and comfortable upholstery provides a comfortable feel Resistant to disinfectants, washable and easy-care Ideal for the use in laboratories
Seat height	Stepless seat height setting from 470-610 mm supported by safety gas spring with protective cover	Seat height can be adapted to nearly 95% of all body sizes, the cover protects the gas spring from dust and dirt
Functions / Mechanism	Permanent contact backrest with additional seat inclination adjustment	This mechanism ensures that the backrest responds immediately to any movements of the upper body by following them Thus, the back remains supported all the time The backrest can also be locked into any tilt position if required
	Quick adjustment	There is a continuously variable mechanism for tilting the seat forwards. This ensures that your posture remains relaxed even when you need to bend forwards into your work. Less pressure is exerted on the thigh area, which encourages steady circulation. The problem of sitting all hunched up is masterfully avoided thanks to a mechanism that ensures a minimum angle of 90° between your legs and upper body at all times
	Anti-Shock lock	Every function can be operated comfortable and easy in sitting position The backrest cannot accidentally spring forwards even after the lock has been released
Base	Black 5 star base made from steel shape tube, powder-coated, black Flat design	Very high stability, longevity Flat design prevents stumbling hazard
Castors / Glides	Dual-wheel safety castors with load-sensitive brakes, For hard floors as standard	Chairs are braked when not used which decreases the accident risk
Materials	The materials used are recyclable	Environmentally friendly
Standards	DIN 68 877 German GS "safety tested" mark of confirmity Quality Management System DIN EN ISO 9001	Procuring is insured

Regulation EWG Nr. 1836/93 and Environmental Management System DIN ISO 14001

Warranty	5 year long term warranty, 3 years full warranty	Guaranteed quality and high efficiency
----------	--------------------------------------------------	----------------------------------------

Accessories and options

Armrests	Loop armrests	Made of polyamide, adjustable in width (20 mm)
----------	---------------	------------------------------------------------

	Multifunctional armrest	The armrests are adjustable in height, width and depth to suit the individual user
--	-------------------------	------------------------------------------------------------------------------------

Accessories	Foot ring	The foot ring can be retrofitted by attaching it to the chair column
-------------	-----------	----------------------------------------------------------------------

Options	Aluminum base, polished	
	Frame light grey	