

## **BATPSU-600-7-24VDC – 24VDC Power supply, 2 A with battery charging and 7Ah back up batteries**

### **Overview :**

The BATPSU-600-7-24VDC from Weatherall Equipment and Instruments Ltd is a high quality Switched mode power supply and Battery back up system designed for use with the Riken Keiki 600 series of standalone Gas monitors and their accessories. It delivers up to a 2 Amp output which is sufficient to support a combination of up to 6 instruments and / or sounder beacons from a single unit. The unit comes with 7Ah of battery capacity which is enough for up to 28 hours of back up if only one instrument is connected.



### **Key Features :**

- 2.0 Amp output current
- 24VDC Output
- 7.0 Ah battery capacity . Giving up to 28hours back up ( 1 x OX-600 )
- Highly efficient power conversion - better than 85%
- Constant current battery charging available
- Tamper switch output
- Self resetting electronic fuse

### **Supplied with :**

- 2 x 12 VDC , 7Ah sealed lead acid batteries
- 3 Meters 240VAC power cable for wiring into mains spur \*
- 5 Meters 24VDC output cable for connection to Instruments and other accessories\*
- 2 x Cable Glands

### **Installation Service :**

Our factory trained Engineers are able to offer a comprehensive installation service to your requirements contact us for a quotation

\* Other length are available on request

*Distributed and Supported in the Uk by:*

