

Lovibond® Water Testing Tintometer® Group



MD 100 Suspended solids, no reagents required

Precise Water Analysis in High-Quality Design



The MD 100 has several key features that make it a favorite among users.

Waterproof Design

The IP 68 design of this instrument ensures that the MD 100 remains water tight for up to 1 hour at 0.1 meter.

Don't worry about dropping the instrument into a body of water - it floats!

Accurate, Reproducible Results

The optical system of the MD 100 utilizes LEDs and interference filters which quickly gives you results that you can be confident in.

User Calibration Mode

A one-point calibration is possible. Additionally, all MD 100 instruments have the ability to display readings directly in ABS or %T units.

One-time-Zero Function

Don't waste time waiting for your instrument to Zero after each test. When testing a new sample, zero the instrument once and all subsequent tests of that sample do not require you to re-zero the instrument.

Automatic Data Storage with Transfer Capabilities

The MD 100 automatically stores the last 16 readings with time and date stamp. These results can be transferred to a spreadsheet using the IRiM accessory.

- Lightweight, rugged design for use in the field
- Single unit construction with no parts to lose or break
- Large, easy to read display
- Industry specific parameter combinations available

Part Number: 276150

Ergonomic Design

Whether you're using the MD 100 out in the field or in the lab, the design of the instrument makes it easy to handle and view the display. If you're using the instrument in the lab, the rubber feet on the bottom of the housing eliminates the need for two hand operation or to chase your instrument around the workbench.

Factory Programmed

All MD 100 instruments are supplied ready to use with up to 14 calibration curves.

All you need to do is select the test you need, prepare your sample and test!

Scroll Driven Menu System

The simple interface allows you to quickly reach the test you need. When the instrument is turned on, it will automatically display the last test used.

2-Year Warranty

Industry

Chemical Industry | Food and Beverage Industry | Industries Others | Marine Industry | Municipalities | NGO | Oil and Gas | Pharmaceutical Industry | Power and Energy

Application

Drinking Water Treatment | Raw Water Treatment | Waste-Water Treatment

MD 100 Suspended solids, no reagents required

The MD 100 photometer is a convenient choice for testing up to 14 parameters on a single instrument.

The instrument has a simple user interface and is constructed for field use. Several industry specific versions are available the combine all of the tests you need.

Measuring Range

Test Name	Measuring Range	Chemical Method
Suspended solids 24	10 - 750 mg/l TSS	Turbidity / Attenuated Radiation Method

Technical Data

Light Source	LED
Optics	LEDs, interference filters (IF) and photo sensor in transparent sample chamber. Depending on the version, up to 3 different interference filters are used. Wavelength specifications of interference filters: 430 nm $\Delta\lambda = 5$ nm 530 nm $\Delta\lambda = 5$ nm 560 nm $\Delta\lambda = 5$ nm 580 nm $\Delta\lambda = 5$ nm 610 nm $\Delta\lambda = 6$ nm 660 nm $\Delta\lambda = 5$ nm
Wavelength Accuracy	± 1
Photometric Range	-2600 - 2600 mAbs
Photometric Accuracy	3 % FS (T = 20 °C – 25 °C)
Operation	Foil keypad
Display	backlit LCD (on keypress)
Suitable Vials	Round Cuvettes 24 mm
Calibration	factory calibration and user calibration. Reset to factory calibration possible
Interfaces	Infrared
Internal Storage	internal ring memory for 16 data sets
Power Supply	4 micro batteries (AAA)
Battery Life Time	approx. 17 hours
Auto – OFF	Yes
Clock	Real Time Clock and Date
Portability	Portable
Environmental Conditions	Temperature: 5 - 40 °C rel. humidity: 30 - 90 % (non condensing)
Compliance	CE
Protection Class	IP 68
Dimensions	155 x 75 x 35 mm
Weight	260 g

Delivery Scope

- Instrument in plastic case
- 4 micro batteries (AAA)
- 3 round cuvettes (glass) with lid
- Sealing rings
- Brush
- Instruction manual
- Quick Start Guide
- Certificate (COC)
- Warranty information

Accessories

Title	Part Number
Water sampler, AF 631	170500
Micro batteries (AAA), set of 4	1950026
Multy cuvette-2, set of 12	197600
Round cuvette 24 mm, set of 12	197620
Sealing ring for round vials 24 mm, set of 12	197626
Round cuvette 24 mm, set of 5	197629
Cleaning cloth	197635
Round cuvette 16 mm, set of 10	197665
Adapter for round cuvettes 16 mm	19802190
Mixing cylinder, 25 ml	19802650
Infrared data transmission modul IRiM	214050
Verification Standard Kit MD 100 / 200	215670
Stirring rod, 13 cm length	364100
Stirring rod, 10 cm length	364109
Stirring rod, 13 cm length, set of 10	364120
Stirring rod, 10 cm length, set of 10	364130
Membrane filter set for use when preparing samples, 25 membrane filters 0.45 μ m, 2 syringes 20 ml	366150
Lid, AF 631	375068
500 ml bottle, AF 631	375069
Brush, 11 cm length	380230
Measuring beaker, 100 ml	384801
Cuvette stand for 6 round cuvettes \varnothing 24 mm	418951
Cuvette stand for 10 round cuvettes \varnothing 16 mm	418957
Plastic funnel with handle (white)	471007
Basic price for calibration certificate for each unit	999845
Additionally for each method	999855