


Disposable Respirator Masks at a glance

Range	Shape	FFP1		FFP2		FFP3
		Unvalved	Valved	Unvalved	Valved	Valved
Premium	Cup-Shaped	-	-	-	8825	8835
	Flat-Fold	-	-	-	Aura 9422+	Aura 9432+
Comfort	Cup-Shaped	8310	8312	8320	8322	8833
	Flat-Fold	Aura 9310+	Aura 9312+	Aura 9320+	Aura 9322+	Aura 9332+
Cool Flow Comfort Valve Gen 3	Flat-Fold			Aura 9320+Gen3	Aura 9322+Gen3	Aura 9332+Gen3
Classic	Cup-Shaped	8710	8812	8810	8822	-
	Flat-Fold	K101	K111	K102	K112	K113
Welding	Cup-Shaped	-	-	-	-	-
Speciality	Cup-Shaped	9906 , 9913 , 9915	9914	-	9922 , 9926	-



Click the code here to go straight to the page!

1. Choose Protection Level	2. Choose valved or unvalved	3. Choose a style
<p>FFP1 – Yellow straps For low level fine dust/oil or water based mists (including hand sanding, drilling and cutting)</p> <p>FFP2 – Blue straps For moderate level fine dust/oil or water based mists (including plastering, cement, sanding and wood dust)</p> <p>FFP3 – Red straps For higher level fine dust/oil or water based mists (including hazardous pharmaceutical powders, biological agents and fibres)</p>	<p>Valved masks;</p> <ul style="list-style-type: none"> • Reduce breathing effort • Are cooler to wear • Stay comfortable for longer • Less likely to mist up eyewear <p>Unvalved masks;</p> <ul style="list-style-type: none"> • Offer lower unit cost • Prevent the wearer contaminating the environment 	<p>Premium Range offer enhanced performance and comfort with a soft face piece sealing ring, valve to reduce heat build-up and 4 point adjustable straps.</p> <p>Comfort Range of cup-shaped masks offers maximum comfort for good user acceptance.</p> <p>Classic Range offer simple and effective protection.</p> <p>Welding range offer protection from dust, mist, metal fumes and ozone during welding.</p> <p>Speciality Range have an active carbon layer for relief from nuisance odours in various specialities from welding to waste sorting</p>

Click the links above to see more about each item, or contact us on 01954 233 110 or sales@camlab.co.uk