



Quick accurate temperature measurement

Checktemp 1 is a high accuracy thermometer with a 1m flexible cable for easy access in hard-to-reach locations.

The sharp-tip stainless steel probe is designed to easily penetrate semi-solid products such as fruit, vegetable and cheese. It can also be used for taking measurements in liquids, air and frozen materials.

Using a thermistor sensor to deliver high levels of accuracy with speed and efficiency, Checktemp 1 is ideal for routine controls and checking incoming and outgoing goods.

100% reassurance with Hanna Cal Check

Hanna's exclusive Cal Check, saves time and brings peace of mind to users in busy catering environments.

In hot kitchens, fast production lines and hectic retail environments, few operators have the time to keep checking the accuracy of their meters. With the Hanna Cal Check, you can verify the accuracy of your meter in seconds - each and every time it is used.

Activated by a simple button, the Cal Check simulates an ice bath of 0.0°C giving a confirmed base reading from which to test.

With a tolerance limit of +/- 0.4°C, you can be completely confident that your measurements are accurate.



Ordering Information

Pocket thermometer with penetration probe | HI-98509

supplied with battery and instructions

Specifications

Product Code	Checktemp1 (HI-98509)
Range	-50.0 to 150.0°C
Resolution	0.1°C
Accuracy	±0.3°C (-20 to 90°C) ±0.5°C (outside)
Probe	stainless steel probe with 1 m cable
Battery Type	1 x 1.5V AAA
Battery Life	approx. 3000 hours of continuous use
Environment	0 to 50°C ; RH max 95%
Dimensions	106 x 58 x 19 mm
Weight	80 g

- Easy read digital display - whatever the viewing angle
- Simple to use with direct probe
- High accuracy
- Calibration feature
- Pocket dimensions
- Simple to use
- 100% accurate, whatever the viewing angle
- Ideal for spot checks
- Instant measurement to HACCP requirements
- Small, lightweight, easy to clean

Authorised distributor



Camlab Ltd
Unit 24 Norman way industrial Estate
Over, Cambridge
CB24 5WE

Tel: 01954 233110
Fax: 01954 233101
Email: sales@camlab.co.uk
Web: www.camlab.co.uk/hanna