

3M™ Jupiter Powered Air Respirator

The Jupiter Powered Air Respirator is comfortable, easy-to-use and provides protection against particulates, gases or vapours, or against a combination of these contaminants depending on the type of filters used.

- ✓ Modern, ergonomic design
- ✓ Suitable for shower decontamination
- ✓ High comfort decontamination belt
- ✓ Electronic **audible and visual alarm** in case of low battery and/or low air flow
- ✓ “Intrinsically Safe” (IS) kit available for use in potentially explosive atmospheres

Approved to EN12941 class TH2 or TH3 dependent on headtop

- ✓ Assigned Protection Factor (APF) of 40 with 3M Versaflo S-Series & M-400 Headtops, APF of 20 with all others



Available either as a starter kit or as individual items



3M™ Jupiter™ Powered Air Starter Kit

This Starter Kit includes a standard 3M™ Jupiter™ Powered Air Turbo including Decontamination Belt and Clip, Filter Gaskets, Air Flow Indicator and Calibration Tube as well as a pair of Organic Vapour and Particulate (A2P) Filters, Pre-filters, Length-adjusting Breathing Tube, 8 hour Rechargeable Battery (NiMH) and a Battery Charger.

Now choose your headtop from pages 11-14

If you have specific system requirements you can make up your own system with the following components:

Turbo Unit	
3M™ Jupiter™ Turbo Unit Includes Decontamination Belt, Air Flow Indicator and Calibration Tube	(085-00-10P)

Filters	
P Filter	(450-00-25P2)
A2P Filter	(453-00-25P2)
A2BEK1P Filter	(453-09-25P2)
ABE1P Filter	(456-18-25P2)
Pre-filter Pack	(461-00-02P24)

Batteries (NiMH)	
Battery Pack - 8 hour	(007-00-64P)
Battery Pack - 4 hour	(007-00-63P)
Battery Pack - 4 hour (intrinsically safe with pouch kit)	(085-12-00P)

Note: A Jupiter™ Turbo Unit that has been used in a dust environment without an intrinsically safe pouch fitted, should never be used for intrinsically safe applications.

Charger	
10 Station Charger	(003-00-59P)
Intelligent Battery Charger	(CHG-02)

Breathing Tubes	
Length Adjusting Breathing Tube	BT-30
Heavy Duty Rubber Breathing Tube	BT-40
Short Lightweight Breathing Tube	BT-20S
Long Lightweight Breathing Tube	BT-20L

