

Lovibond® Water Testing Tintometer® Group



Pooltester Phosphate Test Kit, in plastic case

Determination of Phosphate in low concentration levels



- Highly sensitive
- Easy to use
- Futuristic design
- Highest accuracy

Part Number: 157800

Highly sensitive

With a 9 cm pathlength, this visual test kit is sensitive enough to detect low levels of phosphate in water.

Low cost

This easy-to-use, low cost, testing solution delivers accurate results for measuring the range of 0 - 1000 ppb (= 0 - 1.0 mg/l PO₄).

Industry

Pool Domestic | Pool Services

Application

Pool Water Control

Pooltester Phosphate Test Kit, in plastic case

Does your pool have an algae problem? Algae growth is often a result of phosphate in the pool water. In order to combat the issue, a phosphate binding material can be added to the water, combined with a routine practice of monitoring phosphate levels in the pool. It is important that the solution you choose can accurately detect the low concentration of

200 µg/l PO₄, the level at which an algae bloom can occur.

The Lovibond® Phosphate test kit is up to the task!

Measuring Range

Test Name	Measuring Range
Phosphate	0 - 1000 ppb

Delivery Scope

- Colour card
- Stirring rod, length 13 cm
- Test vial & stopper
- 30 Phosphate No.1 tablets
- 30 Phosphate No.2 tablets
- Instruction Manual

Tintometer GmbH

Lovibond® Water Testing
Schleefstraße 8-12
44287 Dortmund
Tel.: +49 (0)231/94510-0
Fax: +49 (0)231/94510-30
sales@lovibond.com
www.lovibond.com
Germany

Tintometer China

Room 1001, China Life Tower
16 Chaoyangmenwai Avenue,
Beijing, 100020
Tel.: +86 10 85251111 App. 330
Fax: +86 10 85251001
chinaoffice@tintometer.com
www.lovibond.com
China

Tintometer Inc.

6456 Parkland Drive
Sarasota, FL 34243
Tel: 941.756.6410
Fax: 941.727.9654
sales@lovibond.us
www.lovibond.com
USA

The Tintometer Limited

Lovibond House
Sun Rise Way
Amesbury, SP4 7GR
Tel.: +44 (0)1980 664800
Fax: +44 (0)1980 625412
sales@lovibond.uk
www.lovibond.com
UK

Tintometer South East Asia

Unit B-3-12, BBT One Boulevard,
Lebu Nilam 2, Bandar Bukit Tinggi,
Klang, 41200, Selangor D.E
Tel.: +60 (0)3 3325 2285/6
Fax: +60 (0)3 3325 2287
lovibond.asia@tintometer.com
www.lovibond.com
Malaysia

Tintometer India Pvt. Ltd.

Door No: 7-2-C-14, 2nd, 3rd & 4th Floor
Sanathnagar Industrial Estate,
Hyderabad, 500018
Telangana
Tel: +91 (0) 40 23883300
Toll Free: 1 800 599 3891/ 3892
indiaoffice@tintometer.com
www.lovibondwater.in
India

Tintometer AG

Hauptstraße 2
5212 Hausen AG
Tel.: +41 (0)56/4422829
Fax: +41 (0)56/4424121
info@tintometer.ch
www.tintometer.ch
Switzerland

Tintometer Brazil

Caixa Postal: 271
CEP: 13201-970
Jundiaí – SP
Tel.: +55 (11) 3230-6410
sales@tintometer.com.br
www.lovibond.com.br
Brazil

Tintometer Spain

Postbox: 24047
08080 Barcelona
Tel.: +34 661 606 770
sales@tintometer.es
www.lovibond.com
Spain