

LaMotte Smart2 Portable Colorimeter

The user friendly Smart2 colorimeter offers an economical easy to use alternative for field testing. Pre-programmed with 50 tests the unit is direct reading with auto wavelength selection. The entire multi LED optical system is embedded in the optical chamber and optimised for test reagent systems. The microprocessor selects the wavelength and also allows the user to load up to 10 tests for analysing reagent systems.



SPECIFICATIONS

Light source	LED/filter set up at 430,520,630nm
Detector	Photodiode
Range	0 to 125%T
Sample cell	25mm round cell, 10mm square cell or 16mm COD vial
Power	9V or AC adapter
Battery life	500 tests
Data logging	RS232, time and date stamped
Weight	315g

ORDERING INFORMATION

Smart2 colorimeter with 4 sample tubes and AC adapter.

Reference: LE/6605-0500 £690.00

ACCESSORIES
COD adapter

Reference: LE/6605-0503 £19.60