

# Hanna Multi Tester



*A portable laboratory for pH, conductivity, Redox and temperature measurement.*

This meter provides a quick and reliable measurement of the four most important variables in water analysis (pH, ORP, conductivity and temperature). Analysis is simple. After a two and single point calibration for pH and conductivity respectively simply fill the base of the multi tester with your sample, turn the unit on, switch to the desired range and read your measurement.

## SPECIFICATIONS

pH	0 to 14
Redox	-2000 to +2000mV
Conductivity	0 to 1999 $\mu$ S/cm
Temperature	0 to 60°C
Calibration	pH two points, Conductivity one point
Battery	3 off 1.5V (included)
Battery Life	200 hours continuous use.
Weight	260g

## ORDERING INFORMATION

Multi tester complete Reference: HI/6602-4220 £151.20

ACCESSORIES  
Spare batteries each (three required) Reference: FL/6601-0104 £1.70