

4 in 1 Multi-Function Environment Meter

A cost effective introduction to aid conformance to health and safety in the workplace. It measures Sound Levels, Light Levels, %RH and Temperature. The high contrast LCD display has large digits and function indicators.



Features:

- Electric condenser microphone for sound level measuring C frequency at fast response.
- Cosine corrected silicon diode for Lux level.
- Semiconductor sensor for humidity measurement.
- K type input for °C/°F temperature measurements.
- Max hold retains current measured values.
- Max memory displays highest measured value since power on.
- Auto power off prolongs battery life.
- Low battery warning.
- Standard 4mm camera bush for tripod mounting.
- Supplied in carrying case with Lux, RH, Wire temperature sensors, battery, wind muffler and instructions for use.

SPECIFICATIONS

Sound	35 to 130dB
Lux	0 to 20000
%RH	25 to 95%
Temperature	-20 to 750°C
Operating temperature	0 to 40°C
Power	9V PP3 battery
Weight	250g

ORDERING INFORMATION

4 in 1 Environment Meter	Reference: AT/6633-1103	£131.00
4 point calibration certificate.	Reference: AT/6633-1104	£115.00
Instrument tripod	Reference: AT/6633-1105	£37.00