



### Myron pH and ORP Monitor/Controllers 720II Series *Reliable Field Proven design*

The advanced 'isolated' circuitry of the 720 Series II pH/ORP Monitors/controllers guarantees accurate and reliable measurements completely eliminating ground loop and noise issues. The unique sensor pre-amp allows for longer distances between the sensor and the monitor without the loss of accuracy or reliability.

## SPECIFICATIONS

Ranges pH 0-14 or $\pm 2000\text{mV}$
Choice of analogue or digital meters
Advance 'isolated' circuitry
Automatic temperature compensation
Isolated 0-10 VDC recorder output
IP65/NEMA4X water resistant and corrosion proof enclosure
Push to test set point check
Selectable 115/230VAC
CE approved
Unique easy install sensors
Built-in electronic calibration
Single set point/alarm, Adjustable set point hysteresis
Internal set point discourages unauthorized adjustment
<b>Options include:</b>
Second alarm/control module
4-20mA isolated output
Temperature module
Backlit display

## ORDERING INFORMATION

### Myron pH and ORP Monitor/Controllers 720II Series



Details and prices are available on request.